


D4/TX5b




(01) 200000017766(94)

TX5b









- PL** Instrukcja montażu
- DE** Montageanweisung
- GB** Installation instruction
- FR** Instructions de montage
- RU** Инструкция монтажа
- CZ** Návod k montáži
- RO** Instrucțiuni de montaj
- HU** Útmutató
- SK** Návod na montáž

D4/TX5b




	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
D4/TX5b	4	2	6	4	4	4	8	4	4	6	6	8	4	4	8	1	2	6	5	5









A








B







C




D



E



F



	X [mm]
D4/TX5b-130	0
D4/TX5b-140	11
D4/TX5b-150	0
D4/TX5b-160	11
D4/TX5b-170	0
D4/TX5b-180	11

D4/TX5b

