



DJ/PRIII



DJ2/PRIII




SS2/PRIII



DD/PRIII


PRESTIGE

- PL** Instrukcja montażu
- DE** Montageanweisung
- GB** Installation instruction
- FR** Instructions de montage
- RU** Инструкция монтажа
- CZ** Návod k montáži
- RO** Instrucțiuni de montaj
- HU** Útmutató
- SK** Návod na montáž




(01) 2000000152281 (94)


DJ/PRIII, DJ2/PRIII, DD/PRIII, SS2/PRIII




	①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱	⑲	⑳	㉑	㉒	㉓	㉔	㉕	㉖	㉗	㉘	㉙
DJ/PRIII	8	8	6	6	6	2	1	1	1	1	2	1	1	1	1	-	-	1	2	1	1	-	1	1	1	1	1	1	1
DJ2/PRIII	9	9	6	6	6	2	1	1	1	1	2	3	1	1	1	1	1	1	2	-	1	-	1	1	1	1	1	1	1
DD/PRIII	8	8	6	6	6	4	2	2	2	2	-	-	-	2	-	-	1	2	2	-	2	2	2	-	1	1	2	-	
SS2/PRIII	5	5	3	3	-	-	-	-	-	-	-	3	1	1	-	1	1	-	1	-	-	-	-	-	1	-	1	-	-




A






B




C



D




E







DJ/PRIII, DJ2/PRIII, DD/PRIII, SS2/PRIII

F





G









I




J









IV.






M




IV.











P






R







T






U





IV.









Y




Z




IV.




DJ/PRIII



DJ2/PRIII



DD/PRIII



SS2/PRIII

