


Monteringsanvisningar
62252 | 8206yw-L



A		X1	J		X2	S		X1
B		X1	K		X2	T		X1
C		X2	L		X4	U		X8
D		X2	M		X4	V		X16
E		X1	N		X1	W		X5
F		X1	O		X2	X		X10
G		X2	P		X1	Y		X1
H		X1	Q		X1	Z		X1
I		X1	R		X1	Z1		X8

