



Monteringsanvisningar

62881 | R1213





A		X2	H		X1	O		ST4X16	X16
B		X2	I		X4	P		ST4X12	X4
C		X2	J		X4	Q		ST4X12	X6
D		X2	K		X4	R			
E		X2	L		X2	S			
F		X1	M		X1	T			
G		X4	N		X8	U			

